

Quadro® Comil®

SIZE REDUCTION OF DEHYDRATED BANANA PIECES

BACKGROUND

Bananas are a common ingredient in the backing and confectionary industries. For proper results, the banana pieces must be thoroughly dried prior to milling.

COMIL® PERFORMANCE

To size reduce dehydrated banana pieces, Quadro recommends the following tooling run at standard speed:

- Screen: a grater screen ("G" screen)
- Impeller: a square bar impeller (1607 impeller)

A discharge particle size of less than 20 U.S. std mesh may typically be achieved with the Comil®. Actual particle size distribution will vary, depending on the product characteristics specific to the infeed material.

SUMMARY

The Quadro® Comil® easily sizes dehydrated banana pieces.

